

BEDFORD THREE SECTION 72" WALL UNIT CONNECTION

FOR THIS ILLUSTRATION THE UNITS HAVE BEEN IDENTIFIED FOR LOCATION LEFT-CENTER-RIGHT. THERE ARE FOUR LEVELORS IN EACH SECTION THAT CAN BE ADJUSTED WITH A STANDARD SCREW DRIVER, THRU THE HOLES IN THE BOOKCASE BOTTOM. ADJUST THE UNITS BY ALIGNING THE END PANELS, BASE RAIL, AND TOP MOULDING. ONCE THE UNITS ARE POSITIONED, TIE THEM TOGETHER WITH THE CONNECTOR NUTS & BOLTS PROVIDED. NEXT USE THE TWO DIFFERENT SIZED ALLEN WRENCHES TO TIGHTEN THE UNITS TOGETHER. WHEN YOU HAVE FINISHED THE CONNECTION AND SATISFIED WITH THE LEVELING, COVER THE HOLES IN THE BOTTOMS WITH THE BLACK HOLE COVERS PROVIDED. POSITION THE SHELF PINS & PLACE THE ADJUSTABLE SHELVES ON THEM. INSERT THE 10MM BLACK COVER CAPS IN THE HOLES ON OUTSIDE PANELS. SAVE ALLEN WRENCHES IN CASE YOU NEED TO REALIGN OR TAKE APART.

HARDWARE PER EACH UNIT;

- (4) CONNECTOR BOLTS
- (4) CONNECTOR NUTS
- (2) ALLEN WRENCHES
- (12) SHELF PINS
- (4) 5/8 BLACK HOLE COVERS
- (16) 10MM COVER CAPS

