



Nexstep Model 757

1. This chair was designed to seat and support only 1 person.
2. All bolts, screws and knobs must be securely tightened prior to use.
3. Check that all bolts, screws and knobs are tight every 3 months or as needed.
4. Responsibly dispose of packing materials. The plastic covering should not be used as a toy or a head covering as suffocation may result.
5. Only use this chair for its intended purpose. Do not use as a step ladder.
6. Use a mild detergent for cleaning.



Firmly push the 4 - Casters into the Base Frame until you hear them “snap” into place.

ATTENTION: MAKE CERTAIN THAT ALL OF THE SCREWS ARE FULLY TIGHTENED PRIOR TO USING THE CHAIR.

If you have any difficulty with this installation/assembly, please contact our Customer Service department at 1-800-447-3462, ext. 2120.

Goes Great with Work.®

