

Replacement Instructions Seat & Footrest



Step 1: Turn the recliner on its side with the lever (that operates the footrest) facing up as shown in Figure 1 at left.

Step 2: Pull the footrest lever to fully extend the footrest to the open position as shown in Figure 2 at right.



Step 3: Remove the 4 phillips head screws on the bottom of the seat cushion. There are also 4 phillips head screws which secure the foot rest cushion.



Step 4: Remove the 4 phillips head screws on the bottom of the foot rest cushion.