

Sleeper Chair Operating Instructions

1. Lock two casters in front of the chair by stepping on the metal brackets until they click. The casters **MUST** be locked in order to open to the sleeping position.



2. Grasp the loop handle located in the gap under the seat and pull away from the back of the chair. The “ottoman” can then be pulled up from the storage position.



3. Keep pulling on the handle until the mechanism stops. The seat will almost be clear of the front edge of the arms. The inside back of the chair will rotate forward to fill the gap where the seat was inside the arms to create a “pillow” for the sleeping surface.



To return the sleeper chair to the “chair” position, rotate the “pillow” back up against the hard back. Grasp the loop handle and lift the front of the “ottoman” so that it will fit under the seat. Push the seat and “ottoman” back inside the arms making certain that the loop handle is still visible at the front of the seat.